



NOTES:

- METER BOX SHALL BE SET IN SIDEWALK, IF DIRECTED BY DISTRICT.
- ALL SERVICES MUST HAVE INSERTS IN THE TUBING AT THE CORP AND METER STOP.
- INSTALL A MUELLER H-10889 OR FORD A34 METER BUSHING ADAPTER WHEN A 5/8 X 3/4" METER IS INSTALLED
- WHEN INSTALLING A NEW SERVICE AT AN EXISTING LOCATION THE CONTRACTOR MUST REPLUMB THE CUSTOMER SIDE SO THE NEW INSTALLATION MEETS THIS PLAN, AND REMOVE ALL ABANDONED PIPE WITHIN THE METER BOX.
- IRRIGATION METERS WILL REQUIRE A BACKFLOW PREVENTOR PER SCWD STANDARD S-18.
- NEW INSTALLATIONS AT EXISTING LOCATIONS MUST BE RELOCATED INTO THE RIGHT OF WAY.
- WRAP MAIN LOCATER WIRE AROUND SERVICE LINE TO A LENGTH OF APPROXIMATELY 1 FOOT
- FOR C-900 PIPELINES, SADDLES TO BE PLACED NO CLOSER THAN 24" FROM THE BACK OF THE NEAREST BELL OR BLACK INSERTION LINE ON THE SPIGOT END. SADDLES TO BE PLACED A MINIMUM OF 18" APART IF STAGGERED 36" APART IF NOT STAGGERED (ALONG THE SAME LINE).

STD003

SOQUEL CREEK WATER DISTRICT

P.O. BOX 1550

CAPITOLA, CALIFORNIA 95010

CAD: TAD

DATE: JAN-09

CHECKED: MJW

APPROVED: JNG

STANDARD SERVICE CONNECTION

STD. NO.

S-3